
User manual FLXBL60-300-ELE-N-01

Order command : MOTELI00941



Revisions

Version	Modifications	Writer	Checker	Date
1.0	Initial version	HZP	ERIC	02/10/2026

Table of Contents

1. Preface ***3***
- Product Quality Guarantee 3
- Usage Precautions 3
- Safety Precautions 4

2. Product overview ***6***
- Introduction 6
- Functional Features 7
- Technical Parameters 8

3. Pin out ***9***
- J3: Power 48V 9
- J9: GPIO&STO&Logic power 10
- J1&J2: ECAT OUT & ECAT IN 11
- J8: mini-USB 11

4. Electrical specifications ***12***
- Motor Connection 12
- Input Power 12
  - Input Voltage 12
  - Current 12
  - Regenerative Current 13
- Input Port 13
  - Sourcing or sink digital input 13
  - Analog input 15
- High-speed Input Port 15
- Output Port 16
  - Sourcing or Sinkink digital output 16
- Wiring Requirements 18

5. Supplemental directives ***19***
- Copyright 19
- Trademark Designations and Symbols 19
- Target user 19
- Disclaimer: Life Support Systems 19
- Disclaimer: Intended Use 20

6. Dimensions of motor ***21***

7. Frequency-magnitude test curve ***21***

1. Preface

• Product Quality Guarantee

- If the product experiences quality issues within one year of purchase (excluding issues caused by improper operation or failure to meet specified conditions), it can be returned to us for processing after confirmation by our company.
- If the failure is due to improper operation or non-compliance with the specified usage conditions, or if the failure occurs after one year of purchase, a repair fee may be charged. If the product is used in critical applications, we strongly recommend purchasing additional spare units to ensure system continuity and stability.
- When sending a defective product for repair, please ensure that the product is properly packaged. We are not responsible for any damage caused during transportation.
- Repairs typically require several working days, and we appreciate your understanding.
- The following situations are not covered under the product warranty:

A) Failures caused by usage that does not comply with the instructions, conditions, environment, or operations specified in the product manual.

B) Failures resulting from modifications, repairs, or disassembly performed by parties other than our company.

C) Failures caused by usage methods not specified by the company.

D) Failures caused by reasons that could not have been reasonably predicted based on the scientific and technical standards at the time of shipment.

E) Failures caused by force majeure events (such as natural disasters, wars, etc.).

• Usage Precautions

- Please adhere to the rated values and conditions specified in this manual when using the product.
- The design and manufacturing purpose of our products is not for use in life-critical applications or environments. If the product is to be used for special purposes, please inform our sales staff for discussion and confirmation.
- Our company is committed to continuously improving product quality and customer trust. However, when using our products, please ensure the design includes multiple backup systems, fire safety measures, fail-safe mechanisms, etc., to prevent accidents such as personal injury, fires, or other societal damages due to system failure.
- To continuously improve performance, product specifications may be changed or upgraded without prior notice.

• Safety Precautions

To ensure the safety of all users, the following table lists safety precautions to be observed when using this drive board. The precautions are described in detail.

Danger	Indicates that a failure could lead to hazardous situations, with the possibility of death or severe injury.
Attention	Indicates that a failure could lead to hazardous situations, with the possibility of moderate personal injury or minor injury, and potentially material damage.
Prohibition	Indicates that it shall not be violated
Enforcement	Indicates that it must be completed

Danger

- Do not touch the terminal section and its interior with your hands while it is energized. **Otherwise, there is a danger of electric shock.**
- Do not pull or twist the cable, or place heavy objects on the cable. **Otherwise, there is a danger of electric shock and fire.**
- Do not touch any of the rotating parts while the motor is running. **Otherwise there is a risk of being caught in the rotor shaft and causing injury.**
- Do not touch the inside of the driver board with your hands under power-up condition. **Otherwise there is a danger of electric shock.**
- Do not touch the terminals within 5 minutes of the power being turned off. **Otherwise there is a danger of electric shock.**
- Be sure to ground the ground terminals of the driver board and motor. **Otherwise there is a risk of electric shock.**
- Movements, wiring, maintenance, inspection, etc. should be performed after confirming that the power is off and the display light on the panel is completely off. **Otherwise, there is a danger of electric shock.**

Attention

- Do not use this product in places where water, oil, or pharmaceutical droplets may be contaminated, or where corrosive or flammable gases are present.
- Please strictly observe the requirements in the product manual. Otherwise there is a risk of damage to the product or injury to persons.
- The temperature of the driver board, motor, and the surrounding machine itself will rise so please do not touch it. Otherwise there is a risk of burns.
- Use the motor and driver board in the specified combination. Otherwise, there is a risk of fire.
- The heat sink and motor of the driver board may still be in a high temperature state when the power is turned on or shortly after the power is turned off, so do not touch them. Otherwise, there is a risk of burns.
- Do not apply excessive pressure to the edge areas of the housing. Otherwise there is a risk of deformation.
- Ensure that the driver board is installed in a well-ventilated area that is easy to maintain and inspect.
- If the ambient temperature of the driver board is higher than 40℃ , please check the exhaust or ventilation equipment and request forced air cooling.

Prohibition

- Do not use or store the product in places exposed to direct sunlight.
- Do not use the product in places where the ambient temperature and humidity exceed the specified range, or store the product.
- Do not use this product in places where there is a lot of dust, dirt, etc., or store it.
- Do not use or store this product in locations subject to direct vibration or shock.
- Do not use this product in direct sunlight or near magnetic, radioactive or radioactive objects, or store it.
- Do not repair or modify the internal or external structure of this product by yourself.
- Do not install mechanical equipment with high heat generation and electromagnetic interference around the driver board.

Enforcement


- Before starting operation, check that the emergency switch can be activated at any time to stop the machine.
- Maintain at least the following mounting spacing between the driver boards and with other equipment. Ensure adequate mounting spacing as much as possible, otherwise the usability and life of the driver board will be damaged.

2. Product overview

• Introduction

MOTELI00941 is a closed loop BLDC motor with GPIO and ETHERCAT communication.

The input voltage range of the motor drive is DC 12-95V, Inputs and outputs are available. Communication is ETHERCAT or USB.



• Functional Features


- Input power: DC 12 ~ 95V, Minimum supply voltage is 12V, Nominal supply voltage is 48V, Maximum supply voltage is 95V.
- Supports magnetic encoder closed-loop motors with a rated current of 9.2 A.
- 3 general-purpose digital signal inputs, all can be set to high-speed inputs (can be used for fast capture and precise homing).
- 2 configurable digital outputs.
- 1 differential Analog Input ,12-bit resolution (Input: ±10 V)
- Closed-loop control methods: supports pulse/direction mode, communication control mode, and built-in Program IO trigger mode.
- Control signals: enable the drive board, start/stop, emergency stop, limit switch, and other functions.
- Stable and precise current control, with low motor heating.
- Motor protection functions: short circuit protection, over current protection, over voltage protection, under voltage protection, etc.

• Technical Parameters

Item			Content
Adapted motor			BLDC motor
Nominal current			9.2 Arms
Over voltage protection			95VDC
Under voltage protection			12VDC
Digital input / output interface	Input	3 digital signal inputs	can be set to high-speed inputs can be used for fast capture and precise homing
			Optocoupler input voltage 12V ~ 30V（typically 24V） Conduction current 920uA ~ 4.5mA
	Output	2 digital outputs	Photoelectric isolated output voltage 12V ~ 30V（typically 24V）and a maximum saturation current of 30mA
Digital input details			Fast event capture
			Inhibit/Enable motion
			Stop motion under control (hard stop)
			Motion reverse and forward limit switches
			Begin on input
			Abort motion
			Homing
			General purpose
Digital output details			Fast event capture
			Inhibit/Enable motion
			Stop motion under control (hard stop)
			Motion reverse and forward limit switches
			Begin on input
			Abort motion
			Homing
			General purpose
Analog input			+/-10 VDC (12-bit resolution)
LED indication			Status, Fault, ECAT, ECAT IN, ECAT OUT
Communication I/F			USB
			ETHERCAT
Control method			Current loop offset adjustment
			Current loop gain tuning
			Current gain scheduling
			Velocity loop offset adjustment
			Velocity gain tuning
			Velocity gain scheduling
			Position gain tuning
Size			60.8 × 60.8 × 112.3 mm（only includes the motor itself）
Weight			840g
Environmental Specifications	Surrounding Air Conditions		Avoid dust, oil mist and corrosive gases, and avoid installation in direct sunlight or near magnetic, radioactive or radioactive objects.
	Humidity		<85%RH, no condensation
	Operating temperature		-10 ~ +40℃
	Storage temperature		-10 ~ +40℃
	Heat dissipation		Install in a ventilated environment

3. Pin out

• J3: Power 48V



J3	Function
J3-1	Control 48V supply return
J3-2	Control 48V supply return
J3-3	Protective Earth
J3-4	Control 48V supply
J3-5	Control 48V supply




Counterparts: Desuo Precision Industry Co., Ltd.---DOSIN-864-0093

Range voltage between 12 and 95 VDC. Nominal voltage : 48 VDC.

Note : Please ensure correct wiring and pay attention to the power polarity. Ensure no short circuit occurs to prevent damage to the host computer and the driver board.

• J9: GPIO&STO&Logic power



J9	Function
J9-1	Control 24V supply return
J9-2	Opto-isolated digital input 1
J9-3	Opto-isolated digital input 2
J9-4	Opto-isolated digital input 3
J9-5	Digital input return
J9-6	Opto-isolated digital output 1
J9-7	Opto-isolated digital output 2
J9-8	Digital output return
J9-9	Analog input 1
J9-10	Analog input 1 complement
J9-11	Control 24V supply
J9-12	STO 1 opto-isolated input
J9-13	STO 2 opto-isolated input
J9-14	STO signal return
J9-15	Not Connected




Desuo Precision Industry Co., Ltd.---
DOSIN-864-0098

The Range voltage of STO is between 12 and 28.8Volt. Nominal voltage : 24 Volt

The Range voltage of Logic power is between 12 and 95Volt. Nominal voltage : 24 or 48 Volt

Note : Please ensure correct wiring and pay attention to the power polarity. Ensure no short circuit occurs to prevent damage to the host computer and the driver board.

• J1&J2: ECAT OUT & ECAT IN




J1&J2	Function
J1-1	EtherCAT_OUT_TX_P
J1-2	EtherCAT_OUT_TX_N
J1-3	EtherCAT_OUT_RX_P
J1-4	EtherCAT_OUT_RX_N
J2-1	EtherCAT_IN_TX_P
J2-2	EtherCAT_IN_TX_N
J2-3	EtherCAT_IN_RX_P
J2-4	EtherCAT_IN_RX_N



Counterparts : Jiangmen Desuo Connector Co., LTD---RHT-634-3386

The male socket corresponding to the aviation plug equipped with cables can be customized at ELIKO,the name is RHT-634-3386.

• J8: mini-USB



J8	Function
J8	Connect computer



Counterparts : UGREEN mini USB data cable

4. Electrical specifications

• Motor Connection

WARNING **When connecting the motor to the driver board, first make sure that the driver board power is turned off. Verify that unused motor leads are not shorted to other objects. The motor cannot be disconnected while the driver board is energized.**

• Input Power

▪ Input Voltage

The maximum working voltage range for the driver board is 12 ~ 95V DC, with a recommended supply voltage of 48 DC.

A voltage stabilizing capacitor can absorb current spikes on the power line, preventing the driver board from falsely triggering a protection fault.

When operating the driver board at low voltage, it is recommended to parallel a larger stabilizing capacitor at the power input to prevent low voltage alarms caused by unstable power supply.

The driver board is not recommended for use when the supply voltage is below 12V, as it may result in unreliable operation.

When the driver board uses a regulated power supply and the supply voltage approaches 95V, it is recommended to implement voltage clamping measures at the power input to prevent the supply voltage from exceeding 95V, which could trigger an over-voltage alarm and stop the driver board.

When using an unregulated power supply, ensure that the no-load output voltage does not exceed 67V DC, as the rated current of unregulated power supplies is the maximum load current. When the load is lighter, such as when the motor is not running, the actual voltage can reach up to 1.4 times the rated voltage. For smoother and quieter motor operation, it is recommended to use a lower voltage.

▪ Current

The maximum supply current should be the sum of the current from three phases. In general, the required current depends on the motor type, voltage, speed, and load conditions. The actual power supply current is usually much lower than this maximum value because the driver board uses a switching amplifier to convert a high voltage, low current signal into a low voltage, high current signal through a power switch. The rated voltage of the motor windings is often very low, and the higher the supply voltage to the driver board relative to the motor winding's rated voltage, the lower the required power supply current.

- Regenerative Current

When the motor slows down, it acts like a generator, converting the load's kinetic energy into electrical energy. Some energy is absorbed by the driver board and the motor. In applications with large loads running at high speeds, significant kinetic energy may be converted into electrical energy. Typically, simple linear power supplies use a large capacitor to absorb this energy without damaging the system. However, switching power supplies tend to shut down under over-voltage conditions, and the excess energy will be fed back into the driver board, which may trigger an over-voltage alarm and potentially damage the driver board.


• Input Port

- Sourcing or sink digital input


Feature	Details
Standard	Isolated PLC source
Input current	Iin= (Vin-7.4)/4.99 Kohm Iin = 920 uA @ Vin = 12 V Iin = 4.5 mA @ Vin = 30 V
High-level input voltage sourcing mode	12V< Vin <30V
Low-level input voltage sourcing mode	0V< Vin <7V
Minimum pulse width	>250 µsec
Execution time (all inputs): the time from application of voltageon input until execution is complete	0 <T< 250 µsec

Any soft configuration is required to switch sourcing or sinking mode.

a) Sourcing input diagram example




b) Sinking input diagram example



- Analog input

Feature	Details
Minimum input voltage	-10V
Maximal input voltage	10 V




• High-speed Input Port

The driver board has six high-speed inputs, which can be used for fast capture and precise homing.

Feature	Details
Standard	Optocoupler isolated signal
Vih min	2.2V
Vi max	0.6V
Minimum pulse width	>250 usec
Execution time (all inputs): the time from application of voltageon input until execution is complete	0<T<250 usec
High-speed inputs-1-6 minimum pulse width, in high-speed mode	T=5 usec if the input functionality is set to latch/capture (index/strobe). Note: Home mode is high-speed mode and can be used for fast capture and precise homing.

a) Digital input diagram example




• Output Port

- Sourcing or Sinkink digital output


Feature	Details
Standard	Optically isolated PLC sink
Supply output (VDD)	12V to 30V (typically 24V)
Max. output current Iout (max) (V.ut = High)	Iout (max)≤ 30 mA
Collector emitter saturation voltage	1V
Ton (Time from low to high) If Vdd= 24V	<15usec
Toff (Time from high to Low)	<250usec
Output signal common	common negative and common positive compatible

Any soft configuration is required to switch sourcing or sinking mode.

a) Sourcing output diagram example



b) Sinking output diagram example



• Wiring Requirements

- **Please connect the power supply correctly, pay attention to the polarity of the power supply, and make sure that the motor and power connector are correct before powering up!**
- All thread colors mentioned in this article are general, please refer to the real thing!
- When stripping wires, do not put a layer of solder on the wire first, which may prevent proper wiring.
- When wiring, be careful not to kink the core wires, and the core wires must not leak out so as to avoid short-circuiting the wires.
- Please connect the core wires directly, do not solder. Otherwise, sometimes the wire will be broken due to vibration.
- It is strictly prohibited to tin the wire head and connect it to the terminal, otherwise the terminal may be damaged by overheating due to high contact resistance.
- Wiring leads should not be exposed outside the terminals to prevent accidental short-circuiting and damage to the driver board.
- It is strictly prohibited to unplug the strong electric (motor and power) terminals of the drive board with electricity, when the motor stops with electricity, there is still a large current flowing through the coil, and unplugging the strong electric (motor and power) terminals will result in a huge instantaneous induced electromotive force that will burn out the drive board.
- Tighten the terminals with a special tool.
- No pressure should be applied to the wires after wiring.
- In order to prevent interference with the driver board, it is recommended that the control signals use shielded cable lines, and the shield is shorted to ground, in addition to special requirements, the shield of the control signal cable is grounded at one end: one end of the shielded line of the host computer is grounded, and one end of the shielded line of the driver board is suspended. The same machine is only allowed to be grounded at the same point, if it is not a real grounding line, may interfere with the seriousness of the shield layer is not connected at this time.
- If a power supply feeds multiple driver boards, parallel connections should be taken at the power supply, chaining to one and then the other is not allowed.

5. Supplemental directives

• Copyright

ELIKO owns the content of this user manual in its entirety, including but not limited to pictures, logos, trademarks, and resources.

Redistribution of sources or derived formats (for example, Portable Document Format or Hypertext Markup Language) must retain the above copyright notice, and the complete data sheet, user manual, and documentation of this product including associated application notes; and a reference to other available product-related documentation.

• Trademark Designations and Symbols

Trademark designations and symbols used in this documentation indicate that a product or feature is owned and registered as trademark and/or patent either by ELIKO or by other manufacturers, whose products are used or referred to in combination with ELIKO products and ELIKO product documentation.

This user manual is a non-commercial publication that seeks to provide concise scientific and technical user information to the target user. Thus, trademark designations and symbols are only entered in the Short Spec of this document that introduces the product at a quick glance. The trademark designation /symbol is also entered when the product or feature name occurs for the first time in the document. All trademarks and brand names used are property of their respective owners.

• Target user

The documentation provided here, is for programmers and engineers only, who are equipped with the necessary skills and have been trained to work with this type of product.

The Target User knows how to responsibly make use of this product without causing harm to himself or others, and without causing damage to systems or devices, in which the user incorporates the product.

• Disclaimer: Life Support Systems

ELIKO does not authorize or warrant any of its products for use in life support systems, without the specific written consent of ELIKO.

Life support systems are equipment intended to support or sustain life, and whose failure to perform, when properly used in accordance with instructions provided, can be reasonably expected to result in personal injury or death.

Information given in this document is believed to be accurate and reliable. However, no responsibility is assumed for the consequences of its use nor for any infringement of patents or other rights of third parties which may result from its use. Specifications are subject to change without notice.


• Disclaimer: Intended Use

The data specified in this user manual is intended solely for the purpose of product description. No representations or warranties, either express or implied, of merchantability, fitness for a particular purpose or of any other nature are made hereunder with respect to information/specification or the products to which information refers and no guarantee with respect to compliance to the intended use is given.

In particular, this also applies to the stated possible applications or areas of applications of the product. ELIKO products are not designed for and must not be used in connection with any applications where the failure of such products would reasonably be expected to result in significant personal injury or death (safety-Critical Applications) without ELIKO consent.

ELIKO products are not designed nor intended for use in military or aerospace applications or environments or in automotive applications unless specifically designated for such use by ELIKO. ELIKO conveys no patent, copyright, mask work right or other trade mark right to this product. ELIKO assumes no liability for any patent and/or other trade mark rights of a third party resulting from processing or handling of the product and/or any other use of the product.

6. Dimensions of motor



7. Frequency-magnitude test curve

